

# Instruction manual

## OIL-SKIMMER

### JS25 type

#### <Specifications>

Type	JS25-115E,165E,200E,250E,300E
Motor	HF15R050-UTML15NAX 3Phase,200/200/220V,15W×1/50,4P,50/60/60HZ 0.13A HF15R050-UTML15WAX 3Phase,460V,15W×1/50,4P,60HZ 0.12A
Endless belt	25mm(W) B25×800-HP (for JS25-115E) B25×890-HP (for JS25-165E) B25×970-HP (for JS25-200E) B25×1070-HP (for JS25-250E) B25×1170-HP (for JS25-300E)

#### <Before using it>

- ① It is designed to remove supernatant oil and scum from various coolant units.
- ② It is designed to handle oil at low temperature(Max40°C).
- ③ Please affirm whether there is loosening of the bolts or nuts.
- ④ Before starting operation, check that the belt runs in the proper direction.
- ⑤ During electric wiring work for the machine, make sure to install an electromagnetic switch, is set to trigger at 0.11/0.12/0.10/0.11A(50/50/60/60HZ) or less equipped with a thermal relay for motor protection.
- ⑥ Supernatant oil, etc., collected through the scraper chute must be separated by a separator tank.

#### <Warning>

Place the main power disconnect to the OFF position,  
Before cleaning OIL-SKIMMER.

Specifications and dimensions are subject to change without prior notice.